

#2448 – ENGLISH

Women's Stretch Thermal Socks

How to choose the appropriate size: Use the size corresponding to the shoe size.

Seam and hem allowances are included.

Pieces are stitched with right sides together (unless otherwise indicated).

Pattern pieces

- K) Sock front X2
- L) Sock back X2
- M) Sock sole X2


Socks – USE WIDE AND SHORT ZIGZAG STITCH ONLY – DO NOT USE SERGER

- Pin sole to back, matching double notches (fig. 28) and stitch heel, from the center of one single notch (fig. 29) to the other as shown (fig. 30).
- Pin front to back and sole and stitch, from the hem (fig. 31) to the single notch (fig. 32).
- Fold up heel and prolong stitch, from one notch to the other, stitching around toe (fig. 33).
- Fold down heel and continue stitch up to the hem (fig. 34)

HEM

- Fold upper edge of sock by 2 cm (3/4") to wrong side and sew using a zigzag stitch (fig. 35).
- Turn sock right side out. Seam should appear as shown (fig. 36).

Thank you for sewing with Jalie



#2448 – FRANÇAIS

Chaussettes thermales (tissu extensible) pour femmes

Comment choisir la bonne taille : Utiliser la pointure de chaussure.

Les ressources de couture et d'ourlet sont comprises.

Lors de l'assemblage, les pièces du vêtement sont superposées endroit contre endroit (sauf lors d'avis contraire).

Pièces du patron

- K) Devant chaussette X2
- L) Dos chaussette X2
- M) Semelle chaussette X2

Chaussette – COUDRE AU POINT ZIGZAG TRÈS LARGE ET RAPPROCHÉ

- Épingler la semelle au dos de la chaussette en faisant correspondre le cran double (fig. 28) et coudre le talon, du milieu d'un cran simple (fig. 29) à l'autre en passant par le talon (fig. 30).
- Épingler le devant de la chaussette au dos et à la semelle et coudre, de la partie supérieure (fig. 31) au cran simple (fig. 32).
- Relever le talon et poursuivre la couture d'un cran simple à l'autre en passant par le bout du pied (fig. 33).
- Rabattre le talon et continuer la couture jusqu'à la partie supérieure de la chaussette (fig. 34).

OURLET

- Plier la partie supérieure de 2 cm (3/4") (fig. 35) et coudre au point zigzag.
- Retourner la chaussette sur son endroit. Les coutures apparaîtront sur l'endroit tel qu'illustré (fig. 36).

Merci de coudre avec Jalie